



SPARE PARTS CATALOGUE


MINIGP-12 220cc

2025





1. HANDLE LEVER / THROTTLE / CABLES / HOLDERS / PROTECTORS


No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	1765	6921		HANDLEBAR	2
2	5908	4496	5387	THROTTLE	1
3	5389	2987		LEVER, CLUTCH	1
4	1348	7420		GRIP HANDLE	2
5	8716			HOLDER, PIPE	2
6	2062			BOLT M8X16	4
7	0629			BOLT M8X30	2
8	6405			KIT HANDLE COVERS, HANDLEBAR	1
9	4110			CAP, HANDLEBAR	1
10	6067	0528	3642	CABLE, THROTTLE	1
11	4001			CABLE, CLUTCH	1


2. FRONT BRAKE MASTER CYLINDER / CALIPER / REPAIR KIT

No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	7875			FR. BRAKE PUMP J.JUAN	1
2	7965			LEVER, FR. BRAKE PUMP J.JUAN	1
3	8008			BOLT, FR. BRAKE COVER J.JUAN	1
4	7870	4931		HOSE, FR. BRAKE FORMULA / J.JUAN	1
5	2492			RACOR BOLT & WASHER, FR. BRAKE PUMP J. JUAN	2
6	6080			J.JUAN PAD SET	1
7	1715			J.JUAN L. BRAKE CALIPER & PAD SET	1
8	8009			BOLT M10x70, BRAKE CALIPER	2
9	7517			SPACE CENTERING, BRAKE CALIPER	2




3. STEERING STEM (33,5MM) / OP2 (28MM)					
No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	5366			STEM COMP (22MM)	1
2	7053	7054	7055	SET ECCENTRIC UPPER, UNDER PIPE (22M)	1
3	5367			BEARING, HEAD PIPE	2
4	3846	3845		STEM UNDER	1
5	0479			NUT M22, HEAD PIPE	1
6	1741			DUST STEAL	1
7	3848	3847		STEM UP (A)	1
8	6543			STEM UP (B)	1
9	5368			BOLT M14x17, STRG. STEM	1
10	3187	2059		BOLT M8x35	6
11	2062	4808		BOLT M8x16	2
12	1912		7070	SET STEERING STEM	1
1	7145			STEM COMP (21MM)	1
2	3857	3855	5476	SET ECCENTRIC UPPER, UNDER PIPE (21MM)	1




4. FRONT FORK


No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	8295			FORK ASSY (625MM)	1
2	3064	7228		CAP, FORK	1
3	5965			OUTER BODY FORK	1
4	5968			INNER BODY FORK	1
5	5974			R. FOOT, FORK	1
6	5902			L. FOOT, J JUAN FORK	1
7	6480			SLIDE COLLAR	1
8	0298	5617		GUIDE COLLAR	1
9	6481			RING BACK UP	1
10	4442	3805		OIL SEAL	1
11	6638			O-RING, OIL SEAL STOPPER	1
12	1037			SEAL DUST	1
13	1254			BOLT M6x30	4
14	5933			BOLT M6x12	4
15	7190			BOLT M4x12	4
16	3275			HOLDER WHEEL FR.	1
17	3457			FR. FENDER SUPPORT	1
18	4887			SPRING K = 4	1
19	4888			SPRING K = 5	1
20	5599			SPRING K = 6	1
21	6590			SPRING K = 7	1
22	7416			DAMPER COMP. FR.	1
23	4139			DAMPER COMP. FR. ANDREANI	1
24	7229			FORK ADJUSTER	1
25	2294			OIL SEAL AND SEAL DUST	1


5. FRONT WHEEL


No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	5354			NUT M14, FR. WHEEL	1
2	5475			WASHER M14, AXLE WHEEL	1
3	5940			BOLT M8x20, FR. BRAKE DISK	3
4	5052	5053	2789	FR. BRAKE DISK	1
5	2648			SPACER, FR. BRAKE DISK	1
6	3325			L. SPACER, FR. WHEEL	1
7	0635			BEARING, FR. WHEEL	2
8	3532/3534/3535			FR. WHEEL 12" & BEARINGS	1
9	4648			INNER SPACER	1
10	3324			R. SPACER, FR. WHEEL	1
11	5315			AXLE, FR. WHEEL	1
12	26855			FR. TIRE (S)	1
13	1010	2613		VALVE	1




6. REAR BRAKE MASTER CYLINDER / CALIPER					
No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	6738			RR. BRAKE PUMP	1
2	1922			BOLT M6x25	4
3	4579			BOLT M6x10	1
4	1922			BOLT M6x25	1
5	4757			ROD END	1
6	1906			NUT	1
7	7409			COPPER WASHER M10	2
8	0196			RACOR BOLT M10	1
9	5337			HOSE, RR. BRAKE	1
10	0632			SUPPORT, CALIPER	1
11	6348			CENTERING	2
12	2637			MIR RACING RR. CALIPER	1
13	0896			BRAKE PADS	1
14	0035			COPPER WASHER M8	2
15	0197			RACOR BOLT M8	1
16	6589			BRAKE FLUID	1
17	0643	5963		MIR RACING RR. BRAKE KIT (550MM), WITHOUT CALIPPER SUPPORT (*10)	1


7. REAR WHEEL



No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	5354			NUT M14, AXLE RR. WHEEL	1
2	5475			WASHER M14	1
3	5940			BOLT M8x20	3
4	0637			BRAKE DISK	1
5	6959			R. COLLAR, RR. WHEEL	1
6	0635			BEARING	2
7	4647			INSIDE COLLAR, RR. RIM	1
8	3538	3540	3541	WHEEL 12" & BEARINGS	1
9	8013			L. COLLAR, RR. WHEEL	1
10	7966			RR.SPACER SPROKET WHEEL	1
11	8367	1527		SPROKET 39T	1
12	5466			BOLT M10x30	3
13	2983			AXLE, RR. WHEEL	1
14	2686S			RR. TIRE (S)	1
15	1010	2613		VALVE	1


8. FUEL TANK


No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	1995			FUEL TUBE	1
2	3658	3656		FUEL FILTER	1
3	5547			FUEL TAP	1
4	3177			FUEL TANK	1
5	1922			BOLT M6x25	2
6	6656			O-RING, FUEL CAP	2
7	3525	3524	3526	CAP SET	1
8	4698			BOLT M5x12	4
9	4540	5146		MUZ EXPLOSAFE	1




9. EXHAUST MUFFLER					
No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	1887			GASKET, EXHAUST PIPE	1
2	3528			SPRING, PIPE EXHAUST	3
3	8019			COMPLETE PIPE EXHAUST	1
4	1889			M8 NUT	2
5	7914			MUFFLER	1
6	2754			GLASS WOOL	1
7	4460			CONICAL WASHER	1
8	2060			BOLT, M8X10	1
9	7749	(3, 5)		EXHAUST SYSTEM	




10. LEFT STEP / SHIFT PEDAL					
No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	3907			L. HOLDER, STEP	1
2	4498			L. ARM	1
3	1253			BOLT M8x20	1
4	4111			NYLON, ARM	1
5	4460			CONICAL WASHER	2
6	0629			BOLT M8x30	2
7	5381			L. ARM	1
8	3997	3996		FORWARDING, SHIFT	1


11. RIGHT STEP / REAR BRAKE PEDAL

No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	4111			NYLON, ARM	1
2	1924			BOLT M8x40	1
3	4230			R. ARM, STEP	1
4	5380	2387		BEARING, BRAKE PEDAL	1
5	5377			BRAKE PEDAL	1
6	4955			SPACER, BRAKE JOIN	1
7	5381			LEVER TOE	1
8	1923			COUNTERSINK BOLT M6x25	1
9	5379			SPACER, BRAKE PEDAL	1
10	0629			BOLT M8x30	2
11	4460			CONICAL WASHER	2
12	1766			BOLT M6x20	1
13	4815	1687		END, BRAKE	1
14	5980			R. HOLDER, STEP	1


12. SWINGARM


No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	0644			SWINGARM 420	1
2	8021			SPACER, SWINGARM	1
3	5471			NUT M12, SWINGARM	1
4	4419			R. SPACER, SWINGARM 5MM	2
5	1044			BEARING	2
6	3320			AXLE, SWINGARM 250mm	1
7	3146			R. SPACER, SWINGARM 14MM	1
8	5360			COLLAR, REAR CUSHION	2
9	4985			COOPER WASHER 10X14X1,5	1
10	5359			R. SPACER, SWINGARM 16MM	1
11	4427			SUPPORT, CABLE RR. BRAKE	1
12	7384			BOLT M5x10	1
13	1766			BOLT M6x20	2
14	7838	4792	3124	PROTECTOR CHAIN, SWING ARM	1
15	5934			WASHER M6	2
16	1908			NUT M6	2
17	0629			BOLT M8x30	2
18	4697			SUPPORT, RR. WHEEL	1
19	2638			L. ADJUSTER, CHAIN	1
20	2641			R. ADJUSTER, CHAIN	1
21	4435			BOLT M8x55	2
22	6624			E-RING, BOLT	2
23	4102			GUARD CHAIN	1
24	7398			PROTECTIVE COLLAR, SWING ARM	2
25	6955			BOLT M5x8	2
26	7446	7074		CHAIN 415	1


13. REAR SHOCK


No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	5334			BOLT M10x95	1
2	5359			COLLAR, BEARING 10x14x16	4
3	5360			BEARING, ROD ASSY 14x14	4
4	5466	6763		BOLT M10x30	2
5	4433			ROD ASSY, SHOCK	2
6	5373			COLLAR, SHOCK	2
7	7406			BOLT M10x45	1
8	7407			BOLT HEX. M10x45	1
9	4429			L. PLATE, SHOCK ARM	1
10	3024			COLLAR, SHOCK ARM 40x10x10	1
11	6271	5439		RR. SHOCK	1
12	7408			COLLAR, SHOCK	1
13	4430			R. PLATE, SHOCK ARM	1
14	1916			NUT M10	3
15	6983			BOLT M10x40	1
16	5371			WASHER M10	1
17	8024			JOIN REGULATION SHOCK	1
18	8023			UPPER SHOCK SUPPORT	1
19	8025			SHOCK SUPPORT PLATE	1
20	3814			SHOCK SPRING	0

SPRING

No.	Reference	Descripción	
		lbf/in	kgf/mm
20	3100	175	3,1
20	3097	225	4
20	4951	250	4,5
20	3099	275	4,9
20	3815	300	5,3
20	3814	350	6,2
20	3098	400	7,1


14. FRAME BODY


No.	Reference			Description	Reqd No.	€/item
	STD	OP1	OP2			
1	7761			FRAME	1	
2	6289			FR. SUPPORT, COWL	1	
3	4452			NUT M8	2	
4	4104			WASHER M8	6	
5	0629			BOLT M8X30	2	
6	4113			STEERING STOP	2	
7	7415			SPACER STEERING STOP	4	
8	8072			FRONT ENGINE SUPPORT	1	
9	8247			AXLE M10X120	4	
10	5371			WASHER M10	4	
11	1916			NUT M10	4	
12	4460			CONICAL WASHER M8	11	
13	4808			BOLT M8X16	3	
14	5933			BOLT M6X12	2	
15	7144			HOLDER, COIL / CDI	1	
16	4579			BOLT M6X10	4	
17	6704			NYLON, CHASIS	1	
18	8077			PIVOT	2	
19	7764			UP HOLDER SUPPORT	2	
20	8074			BOLT M8X12 HEX	4	
21	1918			AXLE M10X105	1	
22	5934			WASHER M6	2	
23	8076			PIVOT HOLDER	1	
24	4809			BOLT M8X12	4	
25	1253			BOLT M8X20	4	
26	8078			SUB FRAME	1	




AIR JET		
No.	Referencia	Descripción
6	1190	35 / 38 / 40 / 42 / 45 / 48 / 50

MAIN JET		
No.	Referencia	Descripción
7	5069	72 / 74 / 76 / 90 / 92,5 / 95 / 97,5 / 100 / 102 / 102,5 / 103 / 105 / 106 / 107,5 / 108 / 110 / 112 / 112,5 / 115 / 117,5 / 118
7	2473	120 / 122 / 125 / 128 / 130 / 132 / 135 / 138 / 140 / 142 / 145


15. INTAKE BODY					
No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	8075			GASKET, ENGINE	1
2	3247			NOZZLE, ENGINE-CARBURETTOR	1
3	1766			BOLT M6x20	2
4	2571			CLAMP, NOZZLE	1
5	6343			CARBURETTOR PE28	1
6	1190			AIR JET	1
7	5069			MAIN JET	1
8	2855	2854		ADMITION INLET	1
9		8242		ADAPTER PE28	
10		8246		ALUMINIUM NOZZLE	
11		8434		KIT INLET - ADAPTER	
12		8642		AIR FILTER	


16. ELECTRICAL INSTALLATION

No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	5435			WIRING LOOM	1
2	5495			VOLTAGE REGULATOR	1
3	5349			START RELAY	1
4	4754	7680		ON & OFF ENGINE BUTTON	2
5	2110	3941		CDI	1
6	2104			UP COIL & PIPE	1
7	2607	5210		PIPE, SPARK PLUG	1
8	7806			FUSE 15A	2
9	7738			BATTERY 12V	1
10	0543			SPARK PLUG	1
11	7993			BAT. SUPPORT	1
12	8079			BOLT, M6X120	1
13	0198			SILENTBLOCK	3
14	1908			NUT, M6	2
15	1922			BOLT, M6X25	1
16	8035			HOLD RUBBER BAT.	1


17. FAIRINGS

No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	5937			BOLT M6x10	6
2	2498	5993		MUDGUARD FENDER	1
3	4305			BOLT M6x16	1
4	5934			WASHER M6	3
5	4841			NYLON COLLAR, FR. FENDER	1
6	6465	0651		BOLT & WASHER KIT, FR. SCREEN	1
7	5017	2580		FR. SCREEN	1
8	7740			FRONT FENDER	1
9	1254			BOLT M6x30	2
10	4955			SPACER, FR. FENDER	2
11	5524			FAST BOLT	4
12	7741			LOWER FENDER	1
13	7154			CAP, LOWER FENDER	1
14	7408			SPACER, SEAT FENDER	1
15	4104			WASHER M8	1
16	8084			RUBER SILENTBLOCK	1
17	7188			INNER SPACER	1
18	4460			CONICAL WASHER M8	2
19	0629			BOLT M8x30	1
20	2495	6713		SEAT	1
21	6953	2773		SEAT FOAM	1
22	2062	4808		BOLT M8x16	1
23	0340	4708		R. FENDER	1
24	0520			QUICK BOLT KIT FAIRING	
25		8617		SUPPLEMENT, SEAT	1
26		3187		BOLT M8x35	1
27	6643	6666	4787	STICKERS KIT	1


18. ENGINE

No.	Reference			Description	Reqd No.
	STD	OP1	OP2		
1	0653			PLATEN & BOLT M6x8 KIT	1
2	5652			PINION 16T, PLATEN & BOLT M6x8	1
3	5437			ENGINE	1

PINION 415

No.	Reference	Description
2	5652	12D / 13D / 14D / 15D / 16D / 17D / 18D